

## Basic User Instructions



**On newer model phones the feature key may be labeled as follows**

**Find Your Extension** - Press **Feature \*0**, Then the **Intercom** key  
-Extension will be shown on the display

**Transfer a Call** - Press **Feature 70** (While on you are on the Call), Then Enter the Extension

**Transfer a Call To an External Phone Number** - Press **Feature 70** (While on the Call),  
Then your line access code, usually 9  
Followed by the area code and phone number  
\*\*Requires Proper Configuration & Newer Software!

**Transfer a Call Directly to a Mailbox** - Press **Feature 986**, Then the Mailbox Number

**Park a Call** - Press **Feature 74** (While You Are On The Call)

**Retrieve a Parked Call** - Press **Intercom**, Then the Parked Code

**Speakerphone** - Press the **Handsfree** button

**Conference Call** - 1. Place first call, put them on hold, pay attention to which key the call is on  
2. Place second call, press **Feature 3** and the key with your first call

**Call Forward** - Press **Feature 4**, Then Enter the Extension

**Call Forward to an External Phone Number** - Press **Feature 4**,  
Then your line access code, usually 9  
Followed by the area code and phone number  
\*\*\*This will forward all calls that ring at your phone!  
\*\*Requires Proper Configuration & Newer Software!

**Change Display Contrast** - Press **Feature \*7**, Then 1 thru 9 on the Dial Pad (1 thru 4 on older phones)

**Redial** - Press **Feature 5**

**Set Ring Tone** - Press **Feature \*6**

**Page All Phones** - Press **Feature 610**

**Initialize New Mailbox** - Press **Feature 981**,  
Enter a New Password,  
Record Your Name for the Company Directory

**Check Voicemail** - Press **Feature 981**, Then Enter Your Password

**Send a Voicemail** - Press **Feature 980**, Then Enter The Mailbox Number

**Program External Autodial Key** - Press **Feature \*1**,  
Then Press the Key to be Programmed,  
Then Enter the Area Code and Phone Number  
\*\*Key to be Programmed Must Not Be a Line Key or Intercom Key!

**Program Internal Autodial Key** - Press **Feature \*2**,  
Then Press the Key to be Programmed,  
Then Enter the Extension  
\*\*Key to be Programmed Must Not Be a Line Key or Intercom Key!

**Program Feature Key** - Press **Feature \*3**,  
Then Press the Key to be Programmed,  
Then Press Feature and the desired code  
\*\*Key to be Programmed Must Not Be a Line Key or Intercom Key!