## **ROTTWEILER**

VOICE.DATA.SECURITY www.rottweilersystems.com

Log into the voicemail by dialing intercom 777 or by pressing the Message button. Enter your extension number and your password. (Password will be # on initial setup) Record your name (Initial setup only and for Dial by Name) After Login your options are:

Record and send a message (Internal only)
Press 1 to record and 1 to stop recording
Press 1 to re-record
Press 23 to playback
Press \*3 to delete
Press # to save
To send your message enter the extension or extensions you wish to send message to and then press #.

2. <u>Get your Messages:</u> -Press 0 to listen -Press 1 to reply/forward -Press 3 Pause -Press 5 rewind -Press 6 to advance to end -Press \*\*7 to save message -Press # to skip the message -Press \*3 to delete

3. Administer personal greeting: -Press 0 to listen to greeting -Press 1 to create, change or delete a greeting -Press 3 to activate your recording -Press # when finished

5. <u>Personal Options:</u> -Press 4 to change your password -Press 5 to change your name

6. <u>Out calling Options:</u> -Press 1 to configure out calling -Press 3 to change your out calling number -Press 6 to turn off out calling -Press 9 to turn on out calling -Press \*7 to return to menu options.

## 770-529-5678 6221 Autumn View Place Acworth, Georgia 30101