

NEC VOICEMAIL TIME CHANGE



NEC 824

1. Press FNC
2. Dial 9# (You can use the # and * to move the cursor to desired position)
3. Hour setting: Dial 1, 0
4. Minute setting: Dial 1, 5
5. AM/PM setting: Press RECALL Key
6. Press HOLD key for setting the Calendar
7. Month Setting: Dial 0, 2
8. Day Setting: Dial 0, 9
9. Day of the Week Setting: Dial 1 (digits 0 - 6) *** SEE NOTE
10. Year Setting: Dial 1, 9, 8, 8
11. Press FNC

*** NOTE: The days of the week are entered by the corresponding numbers:

- 0: Sunday
- 1: Monday
- 2: Tuesday
- 3: Wednesday
- 4: Thursday
- 5: Friday
- 6: Saturday

NEC ELITE / PRO I / PRO II / IPK/192/48

1. Set-up, must be done at main Phone/Console. Handset Must be in the cradle.
2. Press FNC or Feature Button
3. Dial 9#
4. Enter Hour and Minute via dial pad
5. Press RECALL to change AM/PM Setting
6. Press HOLD to change the Calendar setting or press FNC to exit programming
7. Press RECALL to select day of the week
8. Dial # to move cursor to day of month field
9. Enter Day of month via dial pad
10. Press RECALL to select Month
11. Dial # to move cursor to year field
12. Enter last 2 digits of the year via dial pad
13. Press FNC of Feature button to Exit programming

NEC IPK 2 AND NEC SV8100

****Note: The Date must be set in system programming (10-01).*

1. To Set the Time:
2. Press the Speaker Key
3. Dial 728
4. Dial two digits for the hour (24-hour clock, 13 = 1:00 PM)
5. Dial two digits for the minutes (00~59)
6. Press Speaker to Hang up


NEC 1400 & 2000 (OLDER MODELS)

Steps	Display
1. With Phone Idle, dial TRF HOLD * TRF HOLD #	CAT MODE
2. Press Speaker	COMMAND
3. Press 03 ANS	03>
4. Press 0 ANS	03>0:-
5. Dial 1234 HOLD	OK
6. Press Speaker Key	Command=
7. Press 02 ANS	02>
Change Year:	
8. Press 0 ANS	02>0:1999-
9. Dial Current year	
10. Press HOLD	OK
11. Lift and Hang up Handset	
Change Date:	
8. Press 1 ANS	02>1:MM/DD/Weekday- (12/07 Mond-)
9. Dial Date (01 for January, 05 for the 5th, 01 Monday, 02 Tuesday, etc.)	
10. Press HOLD	OK
11. Lift and Hang up Handset	
Change Time:	
8. Press 2 ANS	02>2: HHMMSS (current time)
9. Dial the Current time, in Military time (24-hour clock)	
10. Press Hold	
11. Lift and Hang up Handset	

NEC 1400 & 2000 (NEWER MODELS)

Steps	Display
1. With Phone Idle, dial Feature Conf * Feature Conf#	CAT MODE
2. Press Redial	COMMAND
3. Press 03 Recall	03>
4. Press 0 Recall	03>0:-
5. Dial 1234 Conf	OK
6. Press Redial	Command=
7. Press 02 Recall	02>
Change Year	
8. Press 0 Recall	02>0:1999-
9. Dial Current year	
10. Press Conf	OK
11. Lift and Hang up Handset	
Change Date	
8. Press 1 Recall	02>1:MM/DD/Weekday- (12/07 Mond-)
9. Dial Date (01 for January, 05 for the 5th, 01 Monday, 02 Tuesday, etc)	
10. Press Conf	OK
11. Lift and Hang up Handset	
Change Time	
8. Press 2 Recall	02>2:HHMMSS (current time)
9. Dial the Current time, in Military time (24 hour clock)	
10. Press Conf	
11. Lift and Hang up Handset	

NEC 1400 & 2000 - *FROM* *ATTENDANT CONSOLE*

1. Press LOOP Key
2. Press PROG Key (top row, second button)
3. Display = Password
4. Enter Password = 12345678
5. Press CLOCK (top row, third button)
6. Enter 12 Digit Clock information
 - MT DY DW HH MM SS
 - Month (01 - 12)
 - Day (01-31)
 - Day of the Week (00 - 06 = Sun  Sat)
 - Hour (00 - 23)
 - Minute (00 - 59)
 - Seconds (00 - 59)
7. Press ANS
8. Press RLS